

PRØAIM Universal Laptop Workstation (WS-03)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Laptop Work Station



C-Stand Adapter




Laptop Bag



Laptop Mat



4 x Screw



3mm Allen Key

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

FUNCTIONS



Laptop workstation

Compatible with any laptop having length up to 16 inches and width up to 13 inches



Laptop Mat

NON-SLIP
Protects Laptop and Workstation

C-Stand Adapter For Mounting on Stand



3/8\"-16
Tripod Thread

1/4\"-20 Thread

5/8\" Baby Junior Pin

Four Mounting Options:

- Tripod Ball head
- Tripod Base
- Tripod Plate
- C-Stands, Light stands, Arms

Laptop Workstation Setup

- Align the four holes of the laptop workstation with the C-stand adapter holes and screw them together.

Note: The C-stand adapter is attached to the bottom of the laptop workstation.

- Use the Allen key to connect the screws on the top side to the adapter at the bottom and then tighten the adapter knob.

- Mount the laptop workstation on a c-stand and tighten the adapter knob to secure it properly.


Note: Laptop Workstation can be connected in different ways: to a tripod ball head via the 1/4" -20 thread, to the base of your tripod via the 3/8"-16 thread, to a light stand, c-stand, arms via the 5/8" Baby Junior Pin.

- Attach the quick release plate to the c-stand adapter and secure it using the Allen Key.

- Mount the laptop workstation on the tripod ball head and secure it with the knob, as shown in the images.

- Image showing the laptop mat being fitted to a workstation.

Note: The nonslip mat sits on your laptop workstation, providing an anti-slip, anti-scratch surface for electronics and more. In addition, its heat-dispersing air channels help to conduct heat away from laptops and other hot-running electronic devices.



**YOUR PROAIM UNIVERSAL LAPTOP WORKSTATION
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.